

Mike's

**AUTOMOTIVE
MACHINE &
Performance**

www.automachperf.com
ampmike@aol.com

Lifter valley oil splash baffle

The AMP lifter valley oil splash baffle keeps oil away from PCV valve and hot oil off bottom of intake without cutting an old intake gasket.

Easy to install >>>>> No drilling required >>>>> Just drop in

Models for V-6, 350 and 455 Buicks

- #2020 455 T/A SP1, SP2, & Edelbrock intakes
- #2020S for stock 455 intakes
- #2020KB T/A SPX and KB Wildcat (supplied with screw on PCV baffle)
- #2021 T/A Stage 1 350 intake
- #2021SP3 T/A 350 intake
- #2021S Factory iron 350 intake
- #2022 V-6 231 & 3800

- 1 - Clean baffle before installation
- 2 - Place in valley as shown to check for fit (slight twisting may be necessary)
- 3 - Remove baffle and lay an 1/8 inch bead of Right stuff or ultra black silicone on each end rail of block
- 4 - Place baffle in block and press lightly to mate to silicone bead
- 5 - Let set for about 20 minutes
- 6 - Trial fit intake to check for gap between intake and baffle
- 7 - Install and seal gaskets as you would normally do.
- 8 - Lay a bead of silicone 50 % larger than gap on each rail
- 9 - Install intake and torque to spec

